

Evaluating concentration of aerosol particles in occupational hygiene using Optical Particle Counters

Peter Görner, Xavier Simon, Denis Bémer
INRS, Nancy, France

*NIOSH Direct-Reading Exposure Assessment Methods
(DREAM) Workshop, Washington, November 13-14, 2008*


Principles of direct reading aerosol measurement

- β - gauge method
 - Piezoelectric method
 - Tapped element method
- } Classical filter,
Automatic weighing
- Electrical mobility method
 - Triboelectrical method
 - Optical Methods

Optical methods

- Measurement of light transmission
 - Transmissionmeters
- Measurement of light scattering
 - Photometers
 - Optical Particle Counters (COP)

Light scattering





Mie's theory of scattered light (1908)

$$I = I_0 \frac{\lambda^2}{4\pi^2 L^2} \cdot \frac{i_1(\alpha, n, \theta) + i_2(\alpha, n, \theta)}{2}$$

I - Intensity of scattered light

I_0 - Intensity of incident light

λ - Wavelength of light

L - Length

i_1, i_2 Intensity functions


n - Particle complex refraction index

α - Particle size parameter ($\pi d / \lambda$)

θ - Angle of scattered light observation

Spatial distribution of scattered energy


$d=3\ \mu\text{m}$, $n=1.5-0i$, $\lambda=960\ \text{nm}$, $0^\circ < \theta < 360^\circ$



Apparatus to measure light scattered by airborne particles

- Photometers
- Optical Particle Counters (OPC)

Opticle cell of a photometer



Photometer does not measure any concentration

What does a photometer measure ?


- I_0 / I ratio for a particle cloud inside the optical sensing volume
- Need to be calibrated with a dust of the same n , ρ , and particle size distribution, as the measured aerosol

Photometer TM data (Hund, D)




Photometer HUND TM digital μP


- Optical cell



Bias map of the photometer (HUND TM digital μ P)



Optical cell of a OPC



- OPC measures particle size resolved number concentration
(Limited at about 10^3 - 10^5 part./m³)

Particle number concentration versus particle mass concentration

$$C_n [\text{nbr.m}^{-3}] \longrightarrow C_m [\text{mg.m}^{-3}]$$

COP response depends on: nbr, d, **n**

Mass concentration depends on: nbr, d, **ρ**

(**n**, **ρ** - particle ref. index and specific mass)

Calculation of particle mass

Particle mass of particle n_i with the diameter d_i is:

$$m_i = \sum n_i \cdot \left(\frac{\pi \cdot d_i^3 \cdot \rho}{6} \right)$$

Total particle mass:

$$m = \sum m_i$$

Conditions:

Particles are spherical with unique and known density ρ

Optically measured diameter equals the geometric d


Calculation of health-related aerosol fractions

$$C_f = C_T \int_0^{\infty} P_{t,r}(d_{ae}) \cdot F_m(d_{ae}) \cdot d d_{ae}$$

$d_{ae} = d (\rho/\rho_o)^{1/2}$ where $\rho_o = 10^3 \text{ kg.m}^{-3}$
(for spherical particles)

Standard NF X43-299, Technical Report CEN

Practical exemple



GRIMM 1.1 OPC

CIP 10-I GRIMM® 1.108 CIP 10-R



OPC: Grimm 1.108
Inhalable aerosol sampler CIP 10-I
Respirable aerosol sampler CIP 10-R

Sampling in Sausage factory. Activity: « Brushing – Coating » and packaging
Aerosol : Fungi spores ($\rho_p \approx 1000 \text{ kg.m}^{-3}$) and carbonate of calcium ($\rho_p \approx 2700 \text{ kg.m}^{-3}$)
Aerosol particle size-distribution in mass : MMAD $\approx 8.75 \mu\text{m}$; GSD ≈ 2.15

Sampling				$\overline{C_N}$	$\overline{C_M}$ (calculation from $C_{N,i}$ by classes of dp_i)					CIP 10-I Inhalable fraction	CIP 10-R Respirable fraction
Date	Start	End	Activityr		Particles are supposed to be spherical						
					Particle specific mass						
					$\rho_p \approx 1000 \text{ kg.m}^{-3}$	$\rho_p \approx 1340 \text{ kg.m}^{-3}$		$\rho_p \approx 2700 \text{ kg.m}^{-3}$			
				part.L ⁻¹	mg.m ⁻³	mg.m ⁻³		mg.m ⁻³	mg.m ⁻³		
05/02/2008	7h30	14h47	Brushing – Counting	637125	12,1	16,2	11.0	3.8	32,7	16,5 ± 0,8	3,4 ± 0,2
06/02/2008	7h32	15h18	Packaging	208455	3,1	4,2	2.8	1.0	8,4	4,1 ± 0,2	0,76 ± 0,04
					Inh	Inh	Thor	Res	Inh	Inh	Res

Grimm terminal filter Particle mass after 2 days sampling: 12,117 mg (INRS sampling head mounted on Grimm)
Air volume sampled in two days : 520 L (05/02/2008) + 560 L (06/02/2008) = 1,080 m³

Average for two
days

$$\overline{C_{M,Grimm}} = \frac{12,117}{1,080} = 11,2 \text{ mg.m}^{-3} \longleftrightarrow 10,1 \pm 0,5 \text{ mg.m}^{-3}$$


Limitations

- Particle sphericity, $d_o = d_p$
- Sensibility on particle optical properties
- Unsensibility to particle density
- Necessity of in situ calibration
- Zero check
- Water haze




Advantage of using OPC in occupational hygiene

- Direct reading measurement
- Time resolved concentration profile
- Possibility of workplace mapping
- Measurement of particle size



Time resolved concentrations for particles of two different sizes

Brushing-coating operation in sausage factory



The END